



TO CHARGE YOUR 2020 E MOKE

IN THE EVENING

To Begin

Vehicle OFF, remove KEY, vehicle in NEUTRAL, engage PARKING BRAKE,
then...

1. ATTACH charging cord to VEHICLE and then to standard US wall outlet.

Charging port is located in front of driver side front wheel, inside fender well.

To connect cord, first open port door, match shape guide/prongs and, insert plug

2. Pull RED BUTTON **OUT**

3. Charge indicator lights will begin BLINKING & that means CHARGING is underway.

Your E MOKE has 2 charge indicator lights. One is next to plug-in port & one indicator light is under hood. Blinking lights indicate car is still charging, SOLID GREEN light = 100% charge.

ALLOW VEHICLE TO CHARGE OVERNIGHT

IN THE MORNING

1. CONFIRM FULL CHARGE before unplugging cord by looking for SOLID GREEN indicator light. SOLID GREEN light = 100% charge.

One indicator light is next to the plug-in port & a second indicator light is under the hood. Blinking lights indicate that car is still charging.

2. PUSH RED BUTTON **IN.**

3. UNPLUG CHARGE CORD from wall & then UNPLUG CHARGER FROM CAR. Store charge cord in vehicle trunk or in clean dry place. Do not leave charge cord plugged in once vehicle is charged.

- **NOTE IF YOU MUST USE AN EXTENSION CORD**

- CORD MUST BE HEAVY GAUGE
- CORD MUST BE NO LONGER THAN 25 FT